



Cub Up

Assembly Instructions




source**tec**

Parts




Assembly at Warehouse



Assemble item B on to both ends of the lid (item A) using the wood screws (item F).


Assembly on Site

2




Assemble item E into the rebate of the desk cut out using wood screws (item F).

3




Place the PET tray (item C) into the desk cut-out.

4



Assemble item D to item E (already fixed to desk in step 2) clamping the PET tray (item C) into place. * When there is variation in the PET tray, an additional washer may be required (item H) behind the PET tray to tighten the fit to the lid and ensure the mechanism works correctly.

5



Place the lid (item A) into the PET tray aligning the pins to the holes. Ensure the lid is flat and press fit down into place.