



Cub Powerhouse Assembly Instructions




source**tec**

Parts




Assembly at Warehouse

1




Assemble the sockets (item C) into the frame (item B) locking into place with the red clips.

2



Run the cable from the sockets out through the aperture at the bottom of the PET tray (item A).


3



Attach the frame with the sockets (item B) to the PET tray (item A) using items E and D.

Assembly on Site

4



Attach the Cub powerstore to the underside of the desk using suitable screws.