



# Cub

## Assembly Instructions




source**tec**

Parts




Assembly at Warehouse



Assemble item B on to both ends of the PET tray (item A) using item E.


Assembly on Site

2




Assemble item C into the rebate of the desk cut out using wood screws (item G).

3




Place the PET tray (item A) into the desk cut-out.

4



Fix the PET tray (item A) into the desk using item F.

5



From the underside, press the sockets into place within the PET tray. Press the two red clips into the underside of the sockets to secure in place.