


# UNO

Installation guide



[sourceceteq.com/global](http://sourceceteq.com/global)

**sourceceteq**

## Installation



Attach the bracket to the back of the UNO module and place on a table edge. Then tighten to secure the UNO by using a 5mm allen key. The standard bracket size is 25 - 30mm, a larger 50mm bracket is available upon request. A packer bracket is also available to lift up the UNO for larger chargers.

## Trouble Shooting

If the UNO module stops working, please try these troubleshooting tips below. After trying all the troubleshooting tips please don't hesitate to call us.



Turn off the UNO module and then press and hold the red thermal reset button on the side until you hear a click.




Check the 800mm male GST drop lead cable is connected to the female starter lead.




Check the starter lead is plugged into the wall socket.

**1.**




Remove rear cover and store in a safe place.

**2.**




Carefully unclip the data blanking-plate using a flat-bladed screwdriver and store in a safe place.

**3.**



Insert the data connector so that the ridge on its lower face engages with the step on the aperture...

**4.**



...then push firmly forwards to engage the flexible clip.

## Warranty

Workstories Ltd offers a 1-year warranty on our Sourcetec range.

This applies only if products have been used within and by standard office conditions. Wear and tear must be expected from normal use and are not covered by the warranty.

Workstories Ltd reserves the right to refuse replacement or repair if we feel that the product has been abused or has been accidentally damaged by another party. Workstories Ltd also reserves the right to attempt to repair any damaged or faulty products before a decision is made to replace them. In this case, we shall not be liable for any loss occurred by the distributor or customer during this period. Workstories Ltd will not be liable whatsoever for any consequential damage, loss or other expenses whether arising out of contact, negligence or otherwise. Any alterations to our products in any manner will automatically nullify any guarantees offered by Workstories Ltd.

## Misuse or unnecessary call out

If a Workstories engineer has to visit your site for an issue due to an incorrect third party's installation or that can be resolved using the troubleshooting steps, there will be a chargeable fee of **£250**.

# sourcetec

sourcetec:global